

BLUELINE PUMP SAVER

The BlueLine PumpSaver is designed to shut down the main pump if the water level falls below the desired height. It will automatically restart the pump when the water level rises above the set point.

Installation:

1. Attach the suction cups to the sump. The bottom of the sensor is at the pump intake.
2. Attach the airline tube to the BlueLine PumpSaver. The airline tube can be trimmed to any length.
3. Plug your main pump into the BlueLine PumpSaver.
4. Plug the BlueLine PumpSaver into the main pump's outlet.
5. Adjust the sensor's height to maintain the desired water level.



